

INSTALLATION INSTRUCTIONS

Parts Included

- 1 Decorative Stopper • 1 Flange • 1 Rubber Washer • 2 Metal Washers •

Tools Needed

- Teflon Tape • Wrench •

1. Place flange onto water supply pipe.
2. Unscrew brass nut from decorative stopper to reveal rubber and metal washers.
3. Slip onto water supply pipe and tighten with wrench.
4. On opposite end, connect to hose of tub faucet.



*For added security, apply teflon tape around thread on decorative stopper before placement.

***For use with bath supplies only. Not intended for use with “potable” water supplies.**