

INSTALLATION INSTRUCTIONS

Parts Included

- 1 Shower Arm • 1 Flange •

Tools Needed

- Teflon Tape •

1. Attach flange to shower arm.
2. Screw shower arm to water supply pipe and hand tighten. (Either on wall or ceiling)

*For added security, apply teflon tape around threads on shower arm before placement.

3. Attach shower head.

