

# **PureWarmth™**

heated elongated toilet seat **K-10349** 

### **Features**

- Heated toilet seat with three adjustable warmth settings: low, medium and high.
- Dual LED lighting offers guiding light when lid is down and task light when lid is lifted.
- Night-light is manually adjustable to two color choices and two brightness levels.
- Compatible with the KOHLER® PureWarmth™ app to adjust seat warmth and lighting brightness to your daily schedule.
- Hidden cord provides a clean look.
- Quiet-Close<sup>™</sup> lid closes slowly and quietly without slamming.
- Quick-Release<sup>™</sup> hinges allow seat to be unlatched from toilet for easy removal and convenient cleaning; no tools required.
- Grip-Tight bumpers add stability and prevent shifting.
- Color-matched plastic hinge.
- Fits most elongated toilets.
- Toilet seats are not returnable to Kohler Co. if opened or outside of original packaging.

### Material

Plastic.

#### Installation

- Requires a dedicated GFCI outlet.
- Installation tool included.

### Components

Additional included component/s: Power Cord Included.



### Codes/Standards

ASME A112.4.2/CSA B45.16 UL 1431 CSA C22.2 No. 64 CSA C22.2 No. 68

## **KOHLER® One-Year Limited Warranty**

See website for detailed warranty information.

### Available Color/Finishes

Color tiles intended for reference only.

**Color Code Description** 


White





# **PureWarmth™**

heated elongated toilet seat K-10349



### **Required Electrical Service**

One circuit required.

120/240 V, 0.6 A, 50/60 Hz

### **Technical Information**

All product dimensions are nominal.

Seat shape type: Elongated

Seat front type: Closed-front

Seat-mounting holes: 5-1/2" (140 mm)

Bluetooth® range: 33 ft (0.8 m)

Bluetooth® version: 4.2

Power cord length: 60" (1524 mm)

#### **Notes**

Install this product according to the installation instructions.

Do not install this seat in a location where: (1) water might be splashed on the product or (2) excessive moisture, high humidity levels, or condensation is present. This will avoid damage to the electronic components.

Do not use an extension cord with this product. To avoid possible product malfunction, do not plug in the seat until instructed to do so. Locate the receptacle at least 6" (152 mm) above the floor, and within a 32" (813 mm) radius measured 2" (51 mm) from the bowl ledge.

