

Installation Information

Item #P0549-8 and P0549-12

Bridge Faucet (Model Number determines the faucet centers)

Warranted only if installed by a qualified licensed plumber. Use Teflon tape on all threaded connections.

Minimum hole size in sink or deck is 1" diameter Maximum deck/sink thickness is 1 ¼"

- 1. Shut off the water supply before installation.
- 2. Minimum hole size of 1" is required in sink or deck at 8" or 12" centers, depending on the model of the faucet you have.
- 3. Insert threaded shanks through the escutcheon and then through the holes in the deck or sink. Place Lockdown nuts on shanks and tighten faucet to deck.
- 4. Attach supply lines to the ½" IPS faucet shanks.
- 5. Remove the aerator from the end of the spout and turn on water supply to flush hot and cold lines until the water is clear.
- 6. Re-install the aerator and enjoy your beautiful faucet.
- 7. Make no adjustments to valves or valve stems. They are tested at the factory for optimum performance.

